

SERPAC #251

Wall Wart **Power Monitor**

Scale: Full
Tolerances: ± 0.010 "

DRILL
5/16" DIA
(4 PLCS)



0.700

0.700

0.700

1.030

0.420



Notes:

1. Cut holes for LCD first, then measure other holes from LCD holes and centerline of case.
2. For best results, use brad point drills for 1/4" and 5/16" holes.
3. The three outboard pins of SW2 that protrude through the PCB may have to be trimmed to clear J4.
4. Suggestion: A Brother P-Touch label-making machine could be used instead of rubdown letters.

File: PwrMonLayout
Date: 2/20/11
dsgoodsell@verizon.net
Nuts and Volts, Feb. 2011