

Reset	•	•		•	•	Uref (A.3)
3.3V	•	•		•	•	Gnd
5.0V	•	•		•	•	S.13 (C.3)
Gnd	•	•		•	•	S.12 (C.4)
Gnd	•	•		•	•	S.11 (C.5)
Vin(9-12V)	•	•		•	•	S.10 (C.2)
(A.0) S.A0	•	•		•	•	S.9 (C.1)
(A.1) S.A1	•	•		•	•	S.8 (C.0)
(A.2) S.A2	•	•		•	•	S.7 (B.7)
(A.3) S.A3	•	•		•	•	S.6 (B.6)
(B.3) S.A4	•	•		•	•	S.5 (B.5)
(B.4) S.A5	•	•		•	•	S.4 (B.1)
				•	•	S.3 (B.0)
				•	•	S.2 (B.2)
				•	•	S.1 (C.6)
				•	•	S.0 (C.7)